We guarantee — —— the quality

WARRANTY CARD

Date of sale

Stock stamp

Model

Serial number

Warranty conditions: According to the Civil Code. 2 years on components. On frame and fixed forks 2 years. Warranty does not cover normal, excessive wear, damage Warranty claims are void: if the product is found to have been damaged by the user, improper handling, improper storage, accident, use for purposes for which the frame and components not intended, etc.; failure to claim under the warranty within the warranty period if the product has not been properly used and maintained according to the instructions for use; after any modifications to the product (e.g. replacement of

components in the fork, inappropriate replacement of the fork, new paintwork of the frame, etc.); after replacement of components that change the geometry of the scooter or the stresses on the frame; failure to claim under the warranty immediately upon discovery of the defect.

The warranty does not cover: torn or deformed threads; paint and stickers after 1 year; geometry of the inner and outer fork legs; defects of the type of clearance; defects caused by dirt or water inside the fork; deformation of the post or damage to the fork crown due to accidents and overloading; creaking noises; extruded, corroded or dirty bearing journals; air or oil leakage caused by dirt or water ingress under the seals, grooves in the sliding parts and corrosion; squealing brakes and slight vibration of the post or damage to the fork crown due to accidents and overloading; creaking noises; extruded, corroded or dirty bearing journals; air or oil leakage caused by dirt or water ingress under the seals, grooves in the sliding parts and corrosion; squealing brakes and slight vibration of the brakes under braking. The warranty does not cover: torn or deformed threads; paint and stickers after 1 year; geometry of the inner and outer fork legs; defects of the type of clearance; defects caused by dirt or water inside the fork; deformation of the post or damage to the fork crown due to accidents and overloading; creaking noises; extruded, corroded or dirty bearing journals; air or oil leakage caused by dirt or water ingress under the seals, grooves in the sliding parts and corrosion; squealing brakes and slight vibration of the brakes under braking.

INSTRUCTIONS FOR USE

For the Royal and Mastr folding models, it is possible to set the BMX handlebars up to 10 degrees forward relative to the head tube axis.

For Split, Royal and Mastr folding models, check the tightening of the folding bolts on the folding joint and handlebar stem. Increase the stem reduction only for risk/ line on stem.

The producer is not responsible for any other components fitting that the standard one.

This scooter with the carrying capacity 150 kg is design to carry one person. Children can only be transported by using child seat.

Warning: After 100 - 150 km we recommend checking the tightening of the spokes in both wheel spacers. It is possible to check and tighten can be done at an authorized dealer or an authorized bicycle bike service.

We recommend to check and service your scooter at an authorized shop or service center at least once a calendar year. We recommend checking the tire pressure before each ride and visual check of technical condition of scooter.

The brake pads must never touch the tires. Worn brake pads must be replaced. Entrust the exchange to a professional bicycle service.

Take care to maintain a safe distance of the kicking leg from scooter and adapt a ride to your physical conditions and the surrounding situation.

Under no circumstances must visibly damaged scooter be used for driving.

After a fall or harder impact, the scooter must to be a properly checked ideally at an authorized dealer or bicycle service and the damage parts replaced immediately.

The company MIBO Scooters s.r.o. nor are individual sellers are not responsible for the liability for damage to health or property caused by incorrect using a scooter.



MIBO SCOOTERS s.r.o., Vidče 447, 756 53 Czech Republic IČO 64619575—DIČ 64619575—obchod@mibo.cz

Assembly instructions:

- 1. Remove all parts of the scooter from the packaging
- 2. Attach the fender brackets to the forks using bolts and nuts.

3. Pulling the brake cable guide tube out of the brake caliper caliper to extend the brake pads to insert the wheels into the the forks. Insert the wheel into the front fork (when using a directional the direction of rotation according to the arrow on the tire), then then the carrier leg (accessory), the washer and tighten firmly with a spanner nuts or tighten the quick-release axles.

4. Insert the handlebars and stem into the steering tube at least to the stop mark, set them flush with the fork and tighten firmly with Allen key number 6.

5. Insert the wheel into the rear fork (pay attention to the direction of the tire), the washer and also firmly tighten the nuts or qr. axles.

6 . Insert the front and rear brake shoes back into the calipers the tubes so that the fitting at the end of the tube fits into the hole the caliper and, if necessary, adjust the deflection with a cross screwdriver on the sides of the brake shoes.

7. Before driving, check and properly tighten all bolted connections (depending on equipment: horns, brake levers, carrier, child seat, brake lever extensions, wheels, head assembly, stem, fenders and everything), fit accessories according to the instructions (tacho,

basket, etc.), adjust brake efficiency, inflate tires on the to the pressure listed on their sidewall, and then, go.

8. In case of installation problems, please contact your nearest authorised service centre, which can be found on our website <u>www.mibo.cz</u> in the shops section.

We wish you a safe journey and many accident-free miles.

Important warning:

- Do not disassemble or modify the scooter.
- Keep the scooter in good technical condition according to the instructions for instructions for use.

Use the scooter in accordance with applicable regulations and laws.

For ensure safety before assembly and use of the scooter, thoroughly read the assembly and use instructions and follow the instructions for use

In case of doubts about the correctness of the assembly or about the technical conditions of the scooter, always contact an authorized dealer oi bike shop.

The instructions for use do not contain exhaustive information on use, maintance, repair or service. For any service, repaire or maintance please contact our an authorized dealer or bike shop.

In case of disposal of the scooter, proceed according to the applicable regulations they are about waste management.

